

Travelallparts.com - Scoutparts.com
2704 S.E. Steele Street
Portland, OR 97202
888-288-0550

International Truck Headliner Installation Instructions

This headliner was made from an original example and test fitted in a truck. In the last few years of making this headliner we have found that there are small variations in the trucks. We believe this is due to the assembly tolerance standards of the time period the vehicles were made. The fit of the headliner may vary from truck to truck. The instructions below will afford you the best fit possible of the headliner.

To Install:

1. Place pieces of masking tape just below each mounting hole on perimeter of the headliner, on the truck. Mark the center of each hole on the masking tape.
2. Place the headliner to the mounting location. Check the alignment on all sides, this will require two persons to hold the headliner in place. Do not push on the center of the headliner this will crease the material and leave a mark.
3. Once you are happy with the alignment, start at the center front mount hole. With an awl or tool similar push the awl through the headliner using the mark on the masking tape as a guide. Install the first retainer in the front center hole.
4. Move to the center rear of the headliner and repeat the process in the two rear center holes.
5. Moving from left and then right alternate front and rear move back and forth installing retainers as you work your way to each door.